

Entrées / Sorties série 33 ou e-CPC
Inputs / outputs family 33 or e-CPC
*Implique 4+5+11 / Involved 4+5+11

Electrovanne fermeture
Closing solenoid
Electrovanne ouverture
Opening solenoid

Sorties relais et alimentation extérieur
Relay outputs and external power supply


Alimentation e-CPC
e-CPC power supply

Mise à terre de la responsabilité du client
Earth connection customer responsibility
Alimentation D22
D22 power supply

+24 Vcc
1.0 A min
e-Power IP

Cablage comme suit:
- [] ou *1,2,3,...,n** à cabler
* *1,2,3,...,n* numero de borne de la boite de jonction
Wired as following:
- [] or *1,2,3,...,n** to be wired
**1,2,3,...,n* junction box terminal number

Le montage et le raccordement électrique doivent être exécutés conformément à la réglementation locale et par du personnel spécialisé !
Installation and electrical connection should be carried out in accordance with local regulations and only by qualified technicians !



ATTENTION / WARNING		
Presses-étoupes / Glands	Taille / Size	Echelle de taille de câble / cable size range
2, 3, 4, 5, 6, 8, 9, 10, 11, 12	M 12	3mm - 6mm
1, 7	M 16	5mm - 10mm
D	M 20	5mm - 13mm



CLA-VAL UK Limited
www.cla-val.co.uk
info@cla-val.co.uk
Reduce your waste - Sort your rubbish

D22

ValvAps
ValvApps
NO. DE DESSIN
Page 01 / 01

CLA-BOX 10
NO
D22-Z-0001
Rev.: D 06/01/15